


USER MANUAL



ABOUT THIS DOCUMENT

This document describes the User Interfaces and controls for the Qolsys home control and automation system. The Home Control system is a centralized smart LCD control panel (IQPanel) that enables and simplifies home security, home control, energy management, home healthcare, and other services. The smart Control Panel uses wireless technology to communicate with a broad set of wireless peripherals and sensors. The panel can also communicate with a centralized Service Provider system, smart phone or a remote system via cellular wireless or broadband technologies. The panel is accessible via an easy to use touch screen interface as well as from any web browser or smart phone. The control panel platform uses an ARM processor and Android operating system.


CERTIFICATION



Document#: IQPANEL-UM-06-14
Revision Date: 6/3/14
Qolsys Part #: QS-9004-VRZ
Software Version: 1.3.4

Conforms to UL Std. 1023, 985 & 1635
Certified to ULC Std. C1023 & S545

ALL-IN-ONE, ALWAYS CONNECTED



CONGRATULATIONS!

We'd like to thank you for making the decision to purchase the IQ Panel. We hope you'll enjoy using it as much as we enjoyed developing it. Our name is Qolsys, (pronounced kwal-siss) and stands for "Quality Of Life Systems." We built our organization on the belief that we can improve the quality of life through innovation and technology. This panel is the culmination of 3 years of development and testing, and we think you'll love it.


It's got everything you need in a single, easy to use device, and because we developed the software using a Google Android operating system, we can continue to refine your experience over time with software updates and innovative new devices.

The IQ Panel is more than just a security panel, it's a home automation and control platform, giving you access and control over what is going on in your home at all times. To take full advantage of the power of this amazing device you'll want to download the free Alarm.com app to your smartphone or tablet. This will be your link to your home when you are away, keeping you connected and ensuring you have the control you need. We've tried to make the panel easy to use, and provide this manual as a reference to help you take advantage of all the features available. If you have questions on anything, don't hesitate to contact your security or home control provider.


Welcome to the future!
-The Qolsys team

HARDWARE OVERVIEW

FRONT



BACK



EMERGENCY BUTTON

Below the 7" Touchscreen are two buttons: Emergency and Home.



The Emergency Button is marked with a "+" sign. This button can be pressed at any time, regardless of the panel's status or the page currently displayed on the screen.

When pressed, the panel will display the emergency services page, with access to police, fire, and medical emergency alarms.



FIND IT



WHOOOPS!



If you press the emergency button by mistake, simply tap the "Home" button or click "Back" to return to the previous page.

EMERGENCY TYPE



Select the icon that represents your emergency type. As soon as you tap the icon the siren will sound and an "emergency sent" message will appear.



SILENCE SIREN



On medical and fire emergencies you can silence the siren by pressing the green button.

CANCEL REQUEST



To cancel an emergency request press the "cancel" button. For security purposes, you will be required to enter a valid user code.



2-WAY VOICE


If your security provider offers 2-Way voice service you may receive a call from a monitoring agent through your panel's speaker and microphone.

ALARM EVENTS

When the alarm is triggered the IQ Panel will sound the siren and display a red alarm screen.

If your security provider offers monitoring service, the panel will automatically contact the monitoring center using the built in cellular connection.

To disarm, touch the screen and enter your passcode.



POLICE



When the system is armed and the alarm is tripped or the you touch the “Police” emergency button the alarm sounds with the “Intrusion” siren and then activates the Two-Way Voice microphone and speaker, if available.

TWO-WAY VOICE

Note that Two-Way Voice services are only activated after an alarm event and may not be available in all areas or with all security providers.

FIRE



When a Smoke or Carbon Monoxide detector is triggered or someone taps the “Fire” panic on the IQ Panel:
•The alarm sounds with the “Fire” siren and then activates the Two-Way Voice microphone and speaker, if available.

HARDWARE

The built in microphone on the front of the panel and the dedicated Two-Way Voice speaker on the side of the panel activate after a connection to the monitoring station has been made.


MEDICAL




When a customer presses their IQ Pendant or indicates a “Medical” emergency from the IQ Panel:
•The alarm sounds with the “Medical” siren and then activates the Two-Way Voice microphone and speaker, if available.

FALSE ALARM

In the event of a false alarm, press disarm and enter your user code. If your system is monitored, be ready to provide your verbal password to your security provider’s monitoring agent if they contact you. If you are unable to provide the correct verbal passcode, the authorities may be contacted.



EMERGENCY PANIC




When you press the Emergency Button the Emergency Panic screen appears. Touching any of the buttons will trigger an alarm manually.

POLICE



An "Intrusion" alarm is triggered when you touch the "Police" panic button. (touching "silent" triggers a silent alarm.)
For your security, once a police siren has been triggered it cannot be silenced without a passcode.



The alarm will sound until you touch cancel.

Note: Touching cancel requires your user code and will cancel the alarm reported to your security provider.



FIRE



A "Fire" alarm is triggered when you touch the "Fire" panic button.

Note: There is no "Silent" function on the button itself, but once you touch it you can silence it.



The alarm will sound until you touch cancel or touch "silence siren"

Note: Touching cancel requires your user code and will cancel the fire alarm reported to your security provider.



MEDICAL



A "Medical" alarm is triggered when you touch the "Medical" panic button. (touching "silent" triggers a silent alarm.)



When the alarm is going off you can cancel it (requires passcode) or silence it until authorities arrive



If you create a silent alarm only the cancel button appears. Touching it requires your user code and will cancel the alarm reported to your security provider.

HOME SCREEN

The home page is the primary page shown on the IQ Panel. It is the first page the user will see, and it is the default page when the user pushes the home button on the panel. It is divided into three sections: The header/status bar, the primary user interface, and the footer/help bar.

The home page displays the most important and most frequently used Apps. It allows the user to arm or disarm the security system; monitor the overall status of the system; view weather, time, and date information; and execute various security, home control, and other functions of the system.

FIND IT



Header or
Status Bar

Primary User
Interface

Footer or
"Help" Bar



7" TOUCHSCREEN



TOUCHSCREEN

In an emergency you need an immediate response to your touch, so we built the IQ Panel with a 7" RESISTIVE TOUCH screen so it even works with gloves, fingernails, etc.

ALERTS



ALERTS

The IQ Panel uses a common alerts system to draw your attention to various items. When you see the alert, touch the screen to find out what information is being shared.

UPGRADE SERVICES



UPGRADE
SERVICES

The IQ Panel is always improving. As new features are developed they may be made available to you. Contact your security provider for details.

STATUS TYPES & COLOR CODES

The header bar is color coded based on system status, and shows the date, time, and current status.

Feb 26, 2013

SYSTEM READY - DISARMED

Tue - 03:07 PM

The **green** header is labeled "System Ready – Disarmed" and indicates that all of the sensors are closed and the system is ready to be armed.

Feb 26, 2013

SYSTEM NOT READY - DISARMED

Tue - 03:10 PM

The **yellow** header is labeled "System Not Ready – Disarmed" and indicates that one or more of the sensors are open. Touch this yellow bar to see a list of open sensors.

Feb 26, 2013

SYSTEM ARMED- AWAY MODE

Tue - 03:12 PM

The **red** header is labeled "System Armed" and indicates the arming type (Stay or Away)
Note: When armed, the home button and panic button will glow red.

STATUS



If you want to know whether your sensors are open or closed, touch the "Status" app on the Home Screen



BACKLIT BUTTONS

The panel's "Panic" and "Home" buttons also illuminate to show panel status.



Green LED when
Disarmed



Red LED when
Armed

To save battery life, these LED lights will NOT illuminate if the panel is running on battery only (during a power outage)

CHECKING STATUS OUTSIDE THE HOME



You can also see the status of your home from your Alarm.com mobile application, or from any web browser by logging into your Alarm.com account.



Go to your device and
search for "Alarm.com"




ARMING

The first icon on the home screen is used for arming and disarming.



PRESS TO ARM

This coincides with the green “System Ready” message in the Header/Status Bar and indicates the system is currently disarmed, ready to arm. Touching this icon will produce the various arming options.



BYPASS

Bypass sensors easily by checking the buttons next to the sensor name on the right side of the screen. The panel even shows you the status of each device for easy reference.



ARM STAY

Arming in “Stay” mode indicates that people will remain inside the home while the system is armed. Devices such as the IQ Motion and the Image Sensor may not be activated in this mode. We encourage users to activate this regularly, especially as they retire for the evening.



ARM AWAY

Arming in “Away” mode indicates that the home will be vacant while the system is armed. All devices, including the IQ Motion and the Image Sensor will be activated in this mode. We encourage users to activate this whenever they leave the home.

FIND IT



ARMING OPTIONS



EXIT SOUNDS

The panel beeps as the arming timer counts down. You can silence these beeps before you choose an arming type.




ENTRY DELAY

The panel will give you time to disarm once a “delay door” has been opened. Turn this off with a touch.

COUNTDOWN TIMER

When you arm “Away” a timer will appear, giving you time to leave the home before the system is activated.



NEED MORE TIME?

Extend your countdown timer for “Away” mode arming by touching the +60 button.

DISARMING


The first icon on the home screen changes appearance when the system is armed.



ARMED

When the system is armed, whether in “Stay” or “Away” mode, the icon turns red and appears “locked.” To disarm, tap this icon.

If a “delay” door is opened the panel will go into a countdown, allowing the user time to enter their code without triggering the alarm. The camera will take a picture and save the image in the camera app.



IQ CAMERA

DISARM PHOTOS


When you disarm the system from the panel, the built-in IQ Camera will automatically take a photograph and store it in your Camera App, along with the date and time the panel was disarmed. (Note: If an invalid user code was attempted, the system will log this as well)

FIND IT



COLOR CODED STATUS

The IQ Panel is designed to make knowing panel status easy. When armed, the buttons, arming button, and header bar will all appear red.



QUICK EXIT



QUICK EXIT (STAY MODE ONLY)

Need to grab the paper? Let the dog out? Head to work early and don't want to wake those asleep? When the system is armed, press “Quick Exit” for a 120 second period where you can open doors without deactivating the system.

WEATHER

The second icon on the home screen is for weather



TODAY'S FORECAST

Today's forecast is displayed on the weather icon with a graphical representation of expected precipitation, as well as the High and Low temperatures for the day.

PRECIPITATION

The forecasted precipitation will be depicted visually on the panel, and will change based on the day's outlook.



SUNNY



PARTLY SUNNY



MOSTLY SUNNY



MOSTLY CLOUDY



FOG



CLOUDY



RAIN



STORMY



SNOW



SLEET



ICE



DUST/HAZE



FIND IT



LOCATION



Your weather reporting is based on your location, which is set by your dealer. When the IQ Panel is installed your dealer indicates your zip code in your Alarm.com account.

FORECAST

4

DAY FORECAST


If you touch the weather icon, you will get a four day weather forecast.

CAMERA/VIDEO**FIND IT**

The third icon on the home screen is Camera/Video app.

**CAMERA/VIDEO APP**

The Camera/Video app is used to access both the IQ Camera as well as up to 5 Image Sensors learned into your panel.

**DISARM PHOTOS**

The IQ Panel will automatically take a photo every time a user attempts to disarm the panel. The 20 most recent images are saved in the camera app under "Disarm Photos" and also store the date, time, and whether the code used was valid.

**IMAGE SENSOR**

The IQ Panel can support up to 5 Image Sensors. When pictures are taken, they will be saved and can be viewed from this app.

STATUS

The first icon on the second row is Status.



STATUS APP

The Status app is divided into four sections: Current Status, Alerts, Alarms and History.

Security Status					
SYSTEM READY - DISARMED					
Sun - 12:36 PM					
CURRENT STATUS		ALERTS 5	ALARMS 1	HISTORY	
No	Name	Group	Chime	Status	History
1	Front Door	10-Entry-Exit-Delay	1	Closed	View
2	Hallway Motion Detector	17-Away-Instant Motion	None	Idle	View
3	instant	15-Stay-Instant Motion	None	Idle	View
4	ge e	17-Away-Instant Motion	None	Idle	View
<div> Back Filter Page Up Page 1 of 3 Page Down </div>					

CURRENT STATUS

The individual security sensors are listed by zone/area. The status and settings for each of the sensors are shown in a list. If more than one page is required for the whole list, use the "Page Up" and "Page Down" buttons to see the entire list. To see the history for a specific sensor, click "View."

ALERTS

Alerts are messages about tampered sensors, low batteries, and failed communications. The total number of unacknowledged Alerts messages appears in the red bubble counter on this tab. The user may acknowledge each message separately, which will then eliminate the message from the list.

ALARMS

Alarms lists all unacknowledged messages about alarm events.

HISTORY

The last tab displays a history for all sensor activity connected to the IQ Panel. The system will store up to 100 events in the history listing.

FIND IT



ALERTS



ALERTS

If the IQ Panel is reporting a new issue, it will display a bubble above the app showing the number of new items that may require your attention.

ACKNOWLEDGE

<input checked="" type="checkbox"/>	Acknowledge	Notice Date
<input checked="" type="checkbox"/>		10:22 AM, Jul-08-2

Acknowledge a single alert by tapping the check box to the left. Acknowledge all the alerts by tapping the check box at the top of the table.

FILTER



You can view specific results by touching the "Filter" button


HOME CONTROL

The second icon on the second row is Home Control.



HOME CONTROL

Control your home automation devices from the panel's interface.




Z-Wave Status

See the status of all your Z-Wave sensors



Door Locks

See the current status of each lock, send "lock" or "unlock" commands



Thermostat

See the current temperature, adjust target temps as desired, switch from heat to cool, auto or off



Lights

Control light modules from the IQ Panel, turns lights on or off as needed



Smart Socket

Control each side of the smart socket, see current energy usage



Other Z-Wave Devices

Pair other Z-Wave devices with the panel and operate their functions from this section



Lock All Doors

Sends a "lock" command to all doors.



Unlock All Doors

Sends an "unlock" command to all doors.

FIND IT




Z-Wave Status



Thermostat



Smart Socket



Door Locks

APPLICATIONS

The third icon on the second row is Apps.



APPS

Since the IQ Panel is built on the Android operating system, you have access to a variety of useful applications, and more to come as they are developed.



CLEAN SCREEN

Pressing this will completely deactivate the touchscreen for 30 seconds, giving you time to clean it off. Press the home button to deactivate.



SAFETY SENSORS

Learn sensors into non-alarm locations such as pool gates, cleaning supply, interior doors, and other items that pose a safety hazard to family members.



HISTORY

See a complete history of all the panel's sensors and systems. (Most recent 100 items are displayed)



ALERTS

See what issues the panel may be experiencing.



PHOTO FRAME

Turn your IQ Panel screen into a digital photo frame when it's not being used.



SOUND SETTINGS

Adjust the sound settings for every aspect of your IQ Panel.

FIND IT



ANDROID DEVELOPERS



ANDROID OS

The IQ Panel is built on Android, which allows Qolsys to add Apps developed by our team as well as by others in the Android Developer Community.

NOTE: For security purposes, the IQ Panel is not open to the Android Market.

UPGRADE SERVICES



UPGRADE
SERVICES

Because the IQ Panel is built on the Android platform, new applications are sure to appear in the future. These new apps will appear on your panel using the upgrade services inside in your panel.


SAFETY SENSORS

Safety Sensors are created when the system is installed, and can be accessed from the Apps page.



SAFETY SENSORS

A way to protect specific areas of your home without triggering false alarms.



Safety sensors function independently from the intrusion security system on the IQ Panel. Safety sensors provide warning information via voice prompts and/or chimes. The warning notifications will be announced anytime that a safety sensor is opened or closed (or motion detected for motion sensors). Safety sensors are defined at the time of installation.

The Safety Sensor app allows the user to manage safety sensor behaviors. Functions are provided to Disable (turn off) the warning notifications, Quick Access (temporarily turn off the warning voice prompts and chimes), and to Enable (turn on) the warning notifications.

The right side of the display includes a list of all of the safety sensors by name and their respective status information (open, closed, or active). The right side of the display contains the safety sensor control functions.

HOW TO DISABLE SAFETY SENSORS

To turn off all of the safety sensor voice prompts and chimes, press the "Deactivate" button on the left side of the display, then enter your user code to authorize. Once disabled, safety sensors will not chime or set off the alarm.

FIND IT



ARMED ALARM

If a safety sensor is opened while the system is armed, then the intrusion alarm will not trip and the system will remain in the Armed state.

QUICK ACCESS



Need to access a safety sensor? Open the Safety Sensor app and press "Quick Access." You will have 300 seconds to open and close the sensor without triggering the chime.

SENSOR LOCATIONS

The following could be great areas of the home to place a safety sensor:

- Pool gate
- Garage door
- Home office
- Toddler bedroom door
- Gun safe
- Medicine cabinet
- Tool shed
- Utility room
- Cleaning supply closet

PHOTO FRAME


Press “Apps” and then select “Photo Frame.”




PHOTO FRAME SCREENSAVER

You can turn your IQ Panel into a digital photo frame with pre-loaded images or your own pictures. This not only disguises it in your home but adds to your decor.

When you open the Photo Frame app, you will see thumbnails of the images saved in the panel, as well as buttons to play slideshow now, edit your settings, and load new images.



Tapping the “Settings” icon will allow you to access settings to customize your photo frame experience with preferences like duration and effects.



FIND IT



PREVIEW



To preview a photo, touch the picture from the photo frame app. It will expand to full screen. To exit, touch the screen again.


ADDING YOUR OWN PHOTOS TO PHOTO FRAME

STEP 1

Insert an SD Card* into your computer **We recommend using a "class 4" or higher SDHC card with 4gb - 16gb storage space*

STEP 2

Copy the images you want on your panel onto the SD Card. Please note the requirements for your photos:



Less than
1MB each



STEP 3

Safely eject the SD Card from your computer.

STEP 4

Insert the SD Card into the slot on the left side of the IQ Panel

**Do not insert SD Card into panel if power is off*



Insert card with the label facing you



Card will slide all the way in.

STEP 5

Touch "Apps"



STEP 6

Touch "Photo Frame"




STEP 7

Touch "Load from SD Card"



STEP 8

Choose one of the following options:



"Replace" deletes the existing photos and saves the new ones in their place
"Add" adds your new photos to the ones already on the panel

STEP 9

Once the photos are loaded they will appear in the preview pane. Press "Start Photo Frame" to test.

FIND IT



REMOVING THE SD CARD

Once you are done with the SD Card you need to safely remove it.

From the home screen, touch "Settings"




Enter your user code


Touch "System Settings"



Touch "SD Card"



Touch "Unmount SD Card"



Remove the SD Card from the back of the panel

SOUND SETTINGS

The sound settings are located within Apps or inside panel settings.



SOUND

Change the way the panel makes noise.

The IQ Panel's sound settings are completely customizable. To edit your sound preferences, tap the "Sound" icon located in "Settings" or inside the "Apps" folder on the home screen.

The following can be toggled on or off individually for sensors, the panel, or safety sensors:

- Panel voices (verbal commands and announcements)
- Panel chimes (beeps, tones, etc)


Volume	Master volume for panel speakers	
Edit Chimes	Customize sounds for individual sensors	
VOICE SETTINGS		
All Voices	Allowing panel to vocalize actions for sensors, system notifications, and safety sensors Is Enabled	<input checked="" type="checkbox"/>
Sensors	Use panel voice to report sensor actions	<input checked="" type="checkbox"/>
Panel	Use panel voice to report system notifications	<input checked="" type="checkbox"/>
Safety Sensors	Use panel voice to report safety sensor actions	<input checked="" type="checkbox"/>
CHIME SETTINGS		
All Chimes	Allowing panel to emit chimes for sensors, system notifications, and safety sensors Is Enabled	<input checked="" type="checkbox"/>
Sensors	Use panel chimes to report sensor actions	<input checked="" type="checkbox"/>
Panel	Use panel chimes to report system notifications	<input checked="" type="checkbox"/>
Safety Sensors	Use panel chimes to report safety sensor actions	<input checked="" type="checkbox"/>
TROUBLE BEEPS		
All Trouble Beeps	Allowing panel to emit trouble chimes for sensors and panel Is Enabled	<input checked="" type="checkbox"/>
Sensor Low Battery	Emitting chime periodically when a sensor reports a low battery Is Enabled	<input checked="" type="checkbox"/>
Sensor Tamper Beeps	Emitting chime periodically when a sensor reports tampering Is Enabled	<input checked="" type="checkbox"/>
Panel Tamper Beeps	Emitting chime periodically when the panel reports tampering Is Enabled	<input checked="" type="checkbox"/>
Edit Trouble Beep Chimes	Customize Trouble Beep Chimes	
Trouble Beeps Timeout	Emit trouble beeps every 3 minutes	

FIND IT



SPEAKER

The panel sounds will emit from the speaker on the left side of the screen.



MASTER VOLUME

Selecting "Volume" allows you to control the panel's master volume. To adjust, touch the bar on the slider and move it from left to right.



SETTINGS


The first icon in the footer/help section is “Settings.”



SETTINGS


Inside settings you'll access a variety of options to customize the panel's interface and abilities to your location and situation. A code is required to access this part of the system.

Users have the ability to adjust various settings to customize their experience. To access this area you will need to enter your master code.



USER SETTINGS (REQUIRES MASTER CODE)

Note: Some features and settings are only accessible if your security provider allows it, so you may see some “greyed out”. Your security provider will be happy to change these settings for you.



FIND IT



MASTER CODE



In order to access the system settings you'll need to enter the MASTER CODE on the account.

To add, edit, or delete user codes, select “User Management” in Settings”

While the account can have many different codes, only the master code has permission to adjust system settings.

DEFAULT CODE

For security purposes the default master code should be changed when the system has been installed in your home:

DEFAULT MASTER CODE:

1234





EDIT SENSOR

Edit the name and behavior of a sensor in the system.




EDIT SENSOR

Change the name of individual sensors

Edit Chimes					
SYSTEM NOT READY - DISARMED					
Sun - 08:08 PM					
No	Type	Name	Group	Chime Type	Edit
1	Door/Window	Front Door	10-Entry-Exit-Delay	Chime 1	
2	Motion	Hallway Motion Detector	17-Away-Instant Motion	None	
3	Motion	instant	15-Stay-Instant Motion	None	
4	Motion	ge e	17-Away-Instant Motion	None	

To edit a sensor, click on the “edit” button on the right side of the sensor list and you will see a page displaying all the sensor details. This includes the sensor name, chime type, and whether voice prompts should be on or off.

Show Details	
SYSTEM READY - DISARMED	
Tue - 03:46 PM	
Sensor Id	7524A0
Sensor Name	Front Door
Chime Type	Chime 1
Voice Prompts	On
Save	
	

Make any changes you like and click “save” to exit.

FIND IT



CUSTOM TEXT TO SPEECH




Because the IQ Panel uses an Android operating system, it can read almost any name and speak it when the sensor is opened.

Customize your system with specific names like “Megan’s Upstairs Window”

To customize a sensor name, select “Custom Description” under “Sensor Name”

Custom Description




SYSTEM SETTINGS

From the home page, press “Settings” and then “System Settings.”

**SYSTEM SETTINGS**

Access your basic system settings like Wi-Fi, sound, and display settings.

**Wireless Settings**

View your current network or connect to new ones

Sound

Adjust the sound settings for your panel

Brightness

Change the panel's brightness

SD Card

See whether the panel detects an SD Card, and safely “eject” that SD Card when you are done using it.

FIND IT



SYSTEM TESTS


Press "Settings" and select "System Tests"



SYSTEM TESTS

Test your panel's systems to ensure everything is running accurately.

The panel provides a variety of different tests you can use to make sure everything is communicating accurately and effectively.



FIND IT




TEST WEEKLY



You should test your system weekly. Contact your security provider who will provide you with details on how to perform your tests.

WI-FI TEST



Test your Wi-Fi connection to ensure it's working properly. *Please note: The test will check the panel's connection to your network or router, but will NOT verify if the router has internet connectivity*

SENSOR TEST



Performing a sensor test should be done regularly. We recommend at least once per week to ensure you catch any issues before they become problems.


WIRELESS SETTINGS

Wi-Fi settings are found inside “Settings” under “System Settings.”



WIRELESS SETTINGS

Connecting to a local Wi-Fi network will allow a wide variety of features and benefits.



To connect to your Wi-Fi, follow the steps below:



Press “Settings”



Enter your master code



Select “System Settings”



Select “Wireless Settings”



Select “Wi-Fi Settings” and choose your network from the list

Enter your network password (if required)

FIND IT



USERS

Access "User Management" in the "Settings".



USERS

Add, delete, or edit the names, access level and individual pass codes for those who access your system.

Id	Name	Type	Expiry Date	Edit	Delete
1	Admin	Master	01/01/3000		
4	Duress	User	01/01/3000		

The IQ Panel allows different users to operate the system. Each user has a unique user code so that the IQ Panel can track who logs into and out of the system. To access User Management, press the "Settings" button and enter your master code. Then tap "User Management." Users have the option to add, edit, or delete users by pushing the corresponding buttons on the screen. Make the desired changes and tap "Save" to exit.

FIND IT



AUTO-UPDATE



When you make a change to a user, it will automatically update the information on your Alarm.com account.

If you make a change to a user on your Alarm.com portal, it will automatically update the information on your IQ Panel.

CODE TYPES



You can create users in the following categories:

Master:

Access panel functions as well as system settings.

User:

Access panel functions, but NOT system settings

Guest:

Used to give access to those users who will only use the panel on a temporary basis.


HELP

The second icon in the footer is “Help”




HELP APP

The “Help” app is divided into four sections: Video tutorials, FAQs, Contact Us, and Documentation.



To watch a video, select the Video Tutorials tab and press “View”



The IQ Panel displays a long list of common questions and their answers.

FIND IT



VIDEO TUTORIALS



The built in library of video tutorials includes video instructions on common questions like “User Codes” and “Connecting Wi-Fi”

FAQs



FAQs

The panel also has a tab with frequently asked questions that allow a user to find an answer the most common questions.

To access these questions, tap the “Help” icon and select “FAQs”. The questions appear in a list and can be expanded by touching the arrow on the left.

CONTACT US


Select the “Contact Us” icon in the bottom right corner.




CONTACT US

An easy way to get contact information for your security provider

Touching this icon will bring you to a page with your provider’s contact information.



The message center tab holds messages from your security provider. To dismiss a message, touch the box to the left of the date and time.



FIND IT



LEGAL

This document is subject to change without notice. Quality of Life Systems ("Qolsys") assumes no responsibility for errors or omissions and disclaims any liabilities and losses experienced as a result of using this document. For the most recent documentation, contact your local vendor or visit us online at www.qolsys.com.

This document may contain images or information used in normal operations of the IQPanel (the "Product"). These may include fictitious names of people and companies. Any similarity to actual names and addresses of businesses or persons is coincidental.

A. Trademarks and patents *Qolsys, the IQPanel name, and the Qolsys logo are trademarks of Qolsys, Inc.*

You agree that all of Qolsys's trademarks, trade names, service marks and other Qolsys logos and brand features, and product and service names are trademarks and the property of Qolsys, Inc. (the "Qolsys Marks"). Without Qolsys's prior permission, you agree not to display or use in any manner the Qolsys Marks. Trade names used herein may be trademarks or registered trademarks of the manufacturers or sellers of the respective products. This Product and the use of this Product may be covered by one or more patents.

B. Software license Agreement Important: This software license agreement ("Agreement") is a legal agreement between Qolsys and You. Read the following terms and conditions before installing or using the software installed on the Product (the "Software"). This agreement provides a license from Qolsys to use the Software on the Product. It also contains warranty information, disclaimers, and liability limitations. Installing and/or using the Software confirms Your agreement to be bound by these terms and conditions. If You do not agree with these terms and conditions, do not install or use the Software or, if already installed, immediately cease all use of the Software..

C. License. Qolsys grants You a personal, non-transferable and non-exclusive right and license to use the object code of its Software on the single Product on which it was provided; provided that you do not (and do not allow any third party to) copy, modify, create a derivative work from, reverse engineer, reverse assemble or otherwise attempt to discover any source code, sell, assign, sublicense, grant a security interest in or otherwise transfer any right in the Software. You agree not to modify the Software in any manner or form, nor to use modified versions of the Software.

D. Term. This Agreement is effective until terminated. You may terminate this Agreement by ceasing use of the Software. Qolsys may terminate this Agreement if You breach any of these terms and conditions. Upon termination of this Agreement for any reason, You agree to cease use of the Software. All provisions of this Agreement relating to (i) disclaimer of warranties; (ii) limitations on liability, remedies, and damages; and (iii) Qolsys proprietary rights, shall survive termination of this agreement.

E. Limited warranty. Please refer to our website, www.qolsys.com, for the latest Warranty and Return Policy applicable to this product.

F. Limitation of liability. Qolsys's sole obligation or liability under this agreement is the repair or replacement of nonconforming Products and/or Software according to the limited warranty referenced above. In no event will Qolsys be liable for damages, whether consequential, incidental, or indirect, nor for loss of data, loss of profits, or lost savings, arising from use or inability to use the Product or Software or documentation even if Qolsys has been advised of the possibility of such damages, nor for any claim by any third party.

G. General. Any materials provided to You by Qolsys shall not be exported or reexported in violation of any export provisions of the USA or any other applicable jurisdiction. Any attempt to sublicense, assign, or transfer any of the rights, duties, or obligations hereunder shall be void. This Agreement shall be governed by and interpreted under the laws of the State of California, United States of America, without regard to conflicts of law provisions. You hereby consent to the exclusive jurisdiction of the state and federal courts located in Santa Clara County, California, to resolve any disputes arising under or in connection with this Agreement, with venue in Santa Clara County, California.

H. Acknowledgment. You acknowledge that You have read and understand this agreement and agree to be bound by its terms. You further agree that this agreement is the complete and exclusive statement of the agreement between You and Qolsys, and supersedes any proposal or prior agreement, oral or written, and any other communication relating to the subject matter of this agreement.

I. Intended use

Use the Product for its intended use only; refer to the data sheet and user documentation. Any use other than the Product's intended use will void any applicable warranties. For the latest Product information, contact your local vendor or visit us online at www.qolsys.com.

J. FCC compliance

Changes or modifications not expressly approved by Qolsys can void the user's authority to operate the Product. This Product has been tested and found to comply with FCC Rules.

This Product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this Product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the Product and receiver.

Connect the affected equipment and the Product to separate outlets, on different branch circuits.

Consult the dealer or an experienced radio/TV technician for help.

K. WARNINGS

Warning: Do not connect the Product to an AC receptacle that is controlled by a switch.

Warning: Do not connect the Product to a High Power AC receptacle.

LEGAL (Cont.)

Warning: This Product should be installed in accordance with the National Fire Alarm Code, ANSI/NFPA 72, (National Fire Protection Association, Batterymarch Park, Quincy, MA 02269). Printed information describing proper installation, operation, testing, maintenance, evacuation planning, and repair service is to be provided with this Product.

Warning: Owner's instruction notice: The Product is not to be removed by anyone except occupant or certified dealer representative.

Warning: This Product and all sensors associated with it (collectively, the "System") should be tested once a week.

Warning: This System must be checked by a qualified technician at least once every three (3) years.

Warning: Users are advised to create their own Fire and Emergency Evacuation plan. Information to create a plan can be found at the following website, National Fire Protection Association (<http://www.nfpa.org/categoryList.asp?categoryID=1979>), United States Fire Administration (<https://apps.usfa.fema.gov/publications/>) or via other equivalent agencies.

Warning: This System **cannot** call the local police station directly ... all Police Panic Alarms and Intrusion Alarms will be sent to the dealer authorized central monitoring station who will then handle calling the local police as necessary. The Product **cannot** be configured to call the local police station.

Warning: This System **cannot** call the local fire station directly ... all Fire Panic Alarms and Fire Detection Alarms will be sent to the dealer authorized central monitoring station who will then handle calling the local Fire Department as necessary. The Product **cannot** be configured to call the local Fire Department.

Warning: This System **cannot** call the local medical emergency personnel directly ... all Medical Panic Alarms will be sent to the dealer authorized central monitoring station who will then handle calling the local medical emergency personnel (often 911 personnel) as necessary. The Product **cannot** be configured to call the local medical emergency personnel (nor local 911 services).

Warning: The terminal block that is mounted inside the Product has 8 connectors for wires. Only the DC power input connections are currently in use (labeled DCIN + and DCIN -). The other connectors are for future usage. There are two additional connectors for the first external sensor (labeled EXT1 + and EXT1 -), two additional connectors for the second external sensor (labeled EXT2 + and EXT2 -), and finally, two additional connectors for an external siren (labeled BUZZER + and BUZZER -).

L. BATTERY INFORMATION & WARNINGS

Main AC-DC Supply Converter

Voltage	Input 100-240V (AC-DC converter)
frequency,	50/60hz
max. input current	0.68A Max
Voltage	output 12V, 2A

Panel Battery

Battery Type	Lithium Ion Polymer battery
Lifetime Power Cycles	300+ Power Cycles (fully charged to fully discharged state)
DC voltage	8.4V max
battery model number	Springpower 704077
max. charging current	400mA
trickle charge current	50mA max
battery capacity in ampere-hours	2500maH

Warning: Battery Capacity Detection: The battery will be automatically monitored for low battery capacity. Warning messages will be sent to the Product and to the Alarm.com Backend informing the customer of the low battery condition (this occurs whenever the current battery capacity falls below 30% of the fully charged capacity). The Product will also provide optional trouble beep warnings for the low battery conditions. The Product warning messages can be viewed on the Security Status / Alerts Tab.

Warning: Battery Unplugged Detection: The battery will be automatically monitored to detect occurrences of the battery being unplugged. Warning messages will be sent to the Product and to the ADC Backend informing the customer of the unplugged battery. The Product will also provide optional trouble beep warnings for the unplugged battery condition. The Product warning messages can be viewed on the Security Status / Alerts Tab.

Warning: Battery Life: Greater than 5 years with use of the Product according to specifications. Change the battery after 5 years of service. .

Warning: Battery Handling: To maximize the life of the battery and for safety reasons the following precautions should be taken:

- The aluminum foil encasing the battery is delicate and should not be exposed to sharp objects such as knives, pins or sharp finger nails
- The battery should not be exposed to water
- Do not leave near a heat source. This will reduce the working life of the battery

LEGAL (Cont.)

- Do not short circuit the battery by connecting the positive terminal to the negative terminal. High currents can be generated resulting in high temperatures and risking fire and personal injury

M. FALSE ALARM WARNINGS

The following warnings cover the likely potential situations that may cause False Alarms Reports (FAR) to be generated.

Cause of FAR: User fails to enter proper pass code or enters the wrong pass code while trying to disarm system.

Prevention: Carefully enter your passcode. Remember your passcode and/or write it down in a safe place that is easily accessible.

Cause of FAR: User fails to exit premise before exit delay timer expires while trying to arm system in Away Mode.

Prevention: Listen to exit beeps and last 10 second voice countdown ... if running out of time, then either press the Extend button to extend the exit delay or press cancel ... and then start the rearming process again once you are ready to leave the premises.

Cause of FAR: User opens a door, but fails to close the door before the exit delay timer expires while trying to arm system in Away Mode, thus causing an exit fault and alarm condition.

Prevention: Be careful to close the door tightly upon exit during the arming process. If an exit fault / alarm does occur, then quickly reenter the home and disarm the alarm.

Cause of FAR: Erroneous fire detection alarm from sensor.

Prevention: During installation, system can be set to require two fire sensor detections prior to generating central monitoring station fire alarm ... note a local fire alarm will still sound to alert the homeowner.

Cause of FAR: Erroneous Carbon Monoxide detection alarm from sensor.

Prevention: During installation, system can be set to require two Carbon Monoxide sensor detections prior to generating central monitoring station gas leak alarm ... note a local fire alarm will still sound to alert the homeowner.

Cause of FAR: Erroneous user fire, medical or police panic alarm generated.

Prevention: Do not press the Emergency button unless there is a real emergency. If the emergency alarm is accidentally activated, then quickly enter the disarm pass code which will then cancel the alarm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class [B] digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe [B] respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

IMPORTANT! Changes or modifications not expressly approved by Qolsys Inc. could void the user's authority to operate the equipment.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device

CAUTION! *This equipment complies with radiation exposure limits set forth for uncontrolled environment. The antenna(s) used for this transmitters must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.*

Cet appareil est conforme avec Industrie Canada RSS exemptes de licence standard (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) ce dispositif ne doit pas causer d'interférences, et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil

ATTENTION! Cet équipement est conforme aux limites d'exposition aux rayonnements définies pour environnement non contrôlé. L'antenne (s) utilisé pour cette émetteurs doit être installé pour fournir une distance de séparation d'au moins 20 cm de toute personne et ne doit pas être installé à proximité ou utilisé en conjonction avec une autre antenne ou émetteur.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.